

Enphase

To complete the system commissioning successfully, you **must** complete the following two steps with the **Enphase** monitoring platform **Enlighten**.

Step 1

Enter the **NMI** (National Meter Identifier).

System

*Name

Installer Reference

*Type
Residential

Third Party Owned (ex: PPA or Leased)

Owner

First Name

Last Name

Email

Phone

Owner will receive **MyEnlighten** for system performance monitoring.

Change Enlighten Version

*National Meter Identifier (NMI)

Location

*Street Address
Enter a location

Street Address 2

*City

*State/Province
South Australia

*Zip/Postal Code

*Country
Australia

Latitude

Longitude

Step 2

Ensure the customer has completed the **Enphase registration** and ensure the inverter is connected to their local network.

Top Tips

Ensure you have selected the correct grid code for Australia Region B (AS/NZS 4777.2:2020) during the commissioning process.