# Solis

To complete the system commissioning successfully, you **must** enter the **NMI** (National Metering Identifier) and Serial Number (SN) into the **Ginglong** monitoring platform **SolisCloud**, by following the steps below:

Step 1:   Enter the **NMI** (National Metering Identifier).

1.In the plant overview page, click "**+**" in the upper right corner and choose "**+ Add Plant**".

2. Complete **NMI** information correctly at the Plant Creation Interface page. Please choose **WA** as the agent.

3.Click "**View Plant**" to next

Step 2:   Enter the Serial Number.

1.Please click "**Add**" to add the datalogger after the plant has been created successfully or you can add datalogger under the device menu.

2.Enter the SN of the logger. The logger SN can be scanned by placing the device SN bar code in the scan box. If you can't scan it, you can also manually input the datalogger SN.

Note – Please Scan or Input the SN of the logger, not the SN on the Inverter.

Top Tips

- To connect to the inverter Wi-Fi Access Point, use the IP Address **10.10.100.254**
- If you need further assistance, contact the Solis After-Sales Service Department:
  Phone: **03 8555 9516**, Email: **service@solisinverters.com.au**
- Ensure you have selected the correct grid code for Australia Region B (AS/NZS 4777.2:2020) during the commissioning process.